

# **TECHNICAL SERVICE BULLETIN**

To: All Powerboss Dealers and Service Managers

From: Powerboss Technical Support

Date: 10/29/2013

Subject: TSB for Uncrating the Collector 34B units

#### Reason for Bulletin

Proper care and uncrating instructions need to be followed to prevent premature failure of flange bearings. (01173010)

## **Improvement**

Follow proper uncrating and unloading procedure.

## Models/Serial Numbers Affected

#### Unpacking

Remove the packaging, open the fastening straps. For reasons of packaging, the handlebar of the Collector 34 is pivoted forwards. First of all, pivot the handlebar to its operating position.

- 1. Loosen the wing bolts on the right and left sides of the handlebar a few revolutions until the handlebar can be straightened up.
- 2. Pivot the handlebar towards the rear and set it to a height convenient for the user.
- 3. Tighten the wing bolts on the right and left sides of the handlebar .

Remove battens and wheel chocks. Place ramps at the rear of the skid and slowly roll the unit off the skid. DO NOT JUST PULL THE UNIT BACK AND LET IT "DROP" OFF THE SKID ON ITS REAR WHEELS!



